

INSPIRE[®]

ROOFING PRODUCTS

www.InspireRoofing.com

Cutting Direction for Inspire on Turret page 1 of 2

Appropriate underlayment must be used, installed as per manufacturer's recommendations.

Cut top of slate at non-exposed edge. Depth of cut is determined by the pitch of the roof, the greater the pitch the less to be removed.

Caution needs to be taken to not over cut the slate into the exposed area. An exposure of 6" will provide the best product coverage. The 2" overlap onto slates below must be maintained.



Cutting Direction for Inspire on Turret page 2 of 2

As the roof progresses towards the top, smaller slates should be used to more tightly conform to the curve of the roof.

Each slate should be cut to maintain spacing with adjacent slate (some gapping beyond the standard recommended ½" will be required).

